Schematic Diagram ..... Model ST-3500 (This schematic diagram may be modified at any



Notes:

S1-1~S1-5 : Selector switch in "FM MONO" position
FM MONO ↔ FM STEREO ↔ FM AUTO ↔ AM

S2-1~S2-3 : Muting/AFC switch in "OFF" position
[(MUTING) ..... OFF ↔ 1 ↔ 2 [DEEP]]
(A F C) ..... OFF ↔ AUTO ↔ AUTO

S3-1~S3-4 : Delay time switch in "CONST" position CONST ↔ HI-LAG

S4 : MPX hi-bland switch in "OFF" position OFF ↔ ON

S501-1~S501-2 : Power source switch in "ON" position

S502 : Voltage selector switch in "110V" position
110V ↔ 120V ↔ 220V ↔ 240V

DC voltage measurements are taken with VTVM from chassis ground.
( ) ..... FM stereo signal reception
〈 〉 ..... Muting switch to ON position and FM mono (or stereo) signal reception
No Mark ..... Muting switch to ON position and FM/AM non-signal reception.